# Engineering Optics

Lecture 33

31/05/2023

by

#### **Debolina Misra**

Assistant Professor in Physics IIITDM Kancheepuram, Chennai, India

 $S \rightarrow$  a light source (may be a sodium lamp)


 $L \rightarrow$  glass plate so that an extended source of almost uniform intensity is formed.

G<sub>1</sub> → a beam splitter a beam incident on G1 gets partially reflected and partially transmitted

M1 and M2 → good-quality plane mirrors having very high reflectivity

One of the mirrors  $(M_2)$  is fixed and the other (usually  $M_1$ ) is capable of moving away from or toward the glass plate G1 along an accurately machined track by means of a screw.

Usually mirrors  $M_1$  and  $M_2$  are perpendicular to each other and  $G_1$  is at 45° to the mirror.




Schematic of the Michelson interferometer.

if  $x_1$  and  $x_2$  are the distances of mirrors  $M_1$  and  $M_2$  from the plate  $G_1$ ,  $d = x_1 - x_2$ 

To the eye the waves emanating from point P will appear to get reflected by two parallel mirrors  $(M_1 \text{ and } M_2)$  – separated by a distance  $(x_1 \sim x_2)$ .

if we use an extended source  $\rightarrow$  if we have a camera, then on the focal plane we will obtain circular fringes, each circle corresponding to a definite value of  $\theta$ 



Schematic of the Michelson interferometer.

Now, if the beam splitter is just a simple glass plate, the beam reflected from mirror  $M_2$  will undergo an abrupt phase change of  $\pi$  (when getting reflected by the beam splitter), and since the extra path that one of the beams will traverse will be  $2(x_1 \sim x_2)$ , the condition for destructive interference will be


$$2d\cos\theta = m\lambda$$

where m = 0, 1, 2, 3, ... and

$$d=x_1\sim x_2$$

and the angle  $\theta$  represents the angle that the rays make with the axis (which is normal to the mirrors as shown in Fig. 15.35). Similarly, the condition for a bright ring is

$$2d\cos\theta = \left(m + \frac{1}{2}\right)\lambda$$



Schematic of the Michelson interferometer.

Thus as we start reducing the value of d, the fringes will tend to collapse at the center


Conversely, if d is increased, the fringe pattern will expand.

if N fringes collapse to the center as mirror  $M_1$  moves by a distance  $d_0$ , then we must have

$$2d = m\lambda$$
$$2(d - d_0) = (m - N)\lambda$$

where we have set  $\theta' = 0$  because we are looking at the central fringe. Thus

$$\lambda = \frac{2d_0}{N}$$



Computer-generated interference pattern produced by a Michelson interferometer.

## Wavelength measurement

This provides us with a method for the measurement of the wavelength. For example, in a typical experiment, if 1000 fringes collapse to the center as the mirror is moved through a distance of  $2.90 \times 10^{-2}$  cm, then


$$\lambda = 5800 \,\text{Å}$$

The above method was used by Michelson for the standardization of the meter. He found that the red cadmium line  $(\lambda = 6438.4696 \text{ Å})$  is one of the ideal monochromatic sources, and as such this wavelength was used as a reference for the standardization of the meter.

In an actual Michelson interferometer, the beam splitter  $G_1$ consists of a plate (which may be about  $\frac{1}{2}$  cm thick), the back surface of which is partially silvered, and the reflections occur at the back surface as shown in Fig. 15.37. It is immediately obvious that beam 5 traverses the glass plate three times, and to compensate for this additional path, one introduces a "compensating plate"  $G_2$  which is exactly of the same thickness as  $G_1$ . The compensating plate is not really necessary for a monochromatic source because the additional path 2(n-1)t introduced by  $G_1$  can be compensated by moving mirror  $M_1$  by a distance (n-1)t, where n is the refractive index of the material of the glass plate  $G_1$ .

#### A point to note

- In an actual Michelson interferometer, the beam splitter  $G_1$  consists of a plate (which may be about 1/2 cm thick),
- The back surface of which is partially silvered, and the reflections occur at the back surface
- The compensating plate is not really necessary for a monochromatic source because the additional path introduced by G<sub>1</sub> can be compensated by moving mirror M<sub>1</sub>
- Q: How many time rays have crossed G<sub>1</sub>?
- What about white light??
- Difficult to adjust M₁ for each λ
- Hence, compensating plate G<sub>2</sub>



## **Application**

- Can be used in the measurement of two closely spaced wavelengths:
- Sodium lamp → emits two closely spaced wavelengths 5890 and 5896 Å

If mirror  $M_1$  is moved away from (or toward) plate  $G_1$  through a distance d, then the maxima corresponding to the wavelength  $\lambda_1$  will not, in general, occur at the same angle as  $\lambda_2$ . Indeed, if the distance d is such that

$$\frac{2d}{\lambda_1} - \frac{2d}{\lambda_2} = \frac{1}{2}$$

and if  $2d \cos \theta' = m\lambda_1$ , then  $2d \cos \theta' = \left(m + \frac{1}{2}\right)\lambda_2$ . Thus, the maxima of  $\lambda_1$  will fall on the minima of  $\lambda_2$ , and conversely, and the fringe system will disappear.

## Application continued

if 
$$\frac{2d}{\lambda_1} - \frac{2d}{\lambda_2} = 1$$

then interference pattern will again reappear. In general, if

$$\frac{2d}{\lambda_1} - \frac{2d}{\lambda_2}$$

is 1/2, 3/2, 5/2,..., we will have disappearance of the fringe pattern; and if it is equal to 1, 2, 3, ..., then the interference pattern will appear.

## Few points to note

- When the mirrors of the interferometer are inclined with respect to each other, making a small angle (i.e., when  $M_1$  and  $M_2$  are not quite perpendicular), *Fizeau fringes* are observed. The resultant wedge-shaped air film between  $M_2$  and  $M_1$  creates a pattern of straight parallel fringes.
- by appropriate adjustment of the orientation of the mirrors- $M_1$  and  $-M_2$ , fringes can be produced that are straight, circular, elliptical, parabolic, or hyperbolic—this holds as well for the real and virtual fringes.

## Experiment in brief

https://www.youtube.com/watch?v=j-u3IEgcTiQ

#### Problem:1

For a sodium lamp, the distance traversed by the mirror between two successive disappearances is 0.289 mm. Calculate the difference in the wavelengths of the  $D_1$  and  $D_2$  lines. Assume  $\lambda$ = 5890 Å

Answer:

$$\frac{2d}{\lambda_1} - \frac{2d}{\lambda_2}$$

is 1/2, 3/2, 5/2,..., we will have disappearance of the fringe pattern; and if it is equal to 1, 2, 3,..., then the interference pattern will appear.

When the mirror moves through a distance 0.289 mm, the additional path introduced is 0.578 mm. Thus

$$\frac{0.578}{\lambda} - \frac{0.578}{\lambda + \Delta \lambda} = 1$$

$$\Delta \lambda = \frac{\lambda^2}{0.578} = \frac{(5890 \times 10^{-7})^2}{0.578} \text{ mm}$$
  
= 6 Å

Assume  $\Delta \lambda \times \lambda \ll \lambda^2$ 

#### Problem:2

In the Michelson interferometer arrangement, if one of the mirrors is moved by a distance 0.08 mm, 250 fringes cross the field of view. Calculate the wavelength

#### Answer:

The wavelength  $\lambda$  in Michelson interferometer is given by following equation.

$$\lambda = \frac{2d_0}{N}$$

Here,  $d_0$  is the distance moved by the mirror, and N is the number of fringes.

$$\lambda = \frac{2(0.08 \,\text{mm}) \left(\frac{1 \,\text{cm}}{10 \,\text{mm}}\right)}{250}$$
$$= 6.4 \times 10^{-5} \,\text{cm} \left(\frac{10^8 \,\text{A}^{\circ}}{1 \,\text{cm}}\right)$$
$$= 6400 \,\text{A}^{\circ}$$

## Thank You